


# The CliniSense LifeTrack™ shelf-life monitor




# Shelf Life Issues

- Shelf life is determined by both time and temperature
- Most materials deteriorate faster at high temperatures
- Some materials “die quickly” at temperature extremes




# The ideal shelf-life monitor

- Is accurate
- Immediately tells if the product is still good
- Has a “gas gauge” to show remaining shelf life
- Can provide a detailed product history record upon request




# The CliniSense LifeTrack™

- Monitors and analyzes temperature history
- Programmed with a material's sensitivity curve
- Displays remaining shelf-life
- Downloads data to a computer



# The LifeTrack unit



US & foreign patents pending


8/21/2004

CliniSense Corporation


5

# LifeTrack Display


- Shows “+” when product is good, “-” when product has expired
- Lifetime indicator bars decrease as the lifetime is used up



# Display in action




# The stability bank algorithm





# Programming a LifeTrack



8/21/2004

CliniSense Corpo  
ration

9

# 1: Find time-temperature data

## TYPE Milbond Adhesive System

Milbond is an elastomeric-epoxy adhesive system for most glass to metal bonding applications. Milbond kits include an adequate quantity of spacer materials requested by the Military to maintain a bond layer thickness of .015" (.38mm). Milbond meets Military specification MIL-A-48611. Milbond can also be used in glass to glass, glass to plastic, metal to plastic, and metal to metal bonding.



### Approximate Curing Times

Mix Ratio	Room Temperature 25°C (77°F)	Oven Temperature 71°C (160°F)
Epoxy 1:1 (by weight)	7 days	3 hours
Primer 1:1 (by volume)	1 hour (to touch) 24 hours (to dry)	Not Recommended


# 2: Download LifeTrack spreadsheet

## LifeTrack File Downloads


To download, right click and select the "Save Target As..." option

	Instructions	Software
	 <p>LifeTrack programming interface</p> <p>LifeTrack package insert</p>	<p><b>Programming spreadsheets</b></p> <p><a href="#">4 parameter (freezing refrigerated, room-temp, drop-dead temp) model</a></p> <p><a href="#">5 parameter (freezing, refrigerated, room-temp-1, elevated temp-2, drop-dead temp) model</a></p> <p><a href="#">Adhesive curing model</a></p> <p><a href="#">model</a></p> <p><a href="#">sm model</a></p> <p><a href="#">e</a></p> <ul style="list-style-type: none"><li>Open</li><li>Open in New Window</li><li>Save Target As...</li><li>Print Target</li><li>Cut</li><li>Copy</li><li>Copy Shortcut</li><li>Paste</li></ul>

# 3: Enter data in spreadsheet




# 4: Program LifeTrack unit





# Programming complete



Reset the unit,  
QC test, and use



# Applications

- Algorithm can track stability ranging from “ice cream” to “rubber tires”
- Medical products & drugs
- Biodefense Diagnostics
- Food
- Chemicals
- Temperature sensitive rubber and plastics




# Data transmission (standard unit)

- Infrared link to Optical RS232 cable
- Compatible with Windows & Linux
- Can be interpreted on the spot or directed to a remote web site
- “Open system” users can control data & applications





# Data playback



```
LifeTrack
Options:
Input: Hold the Life
Output: When the comp
Output: the input dat
Press:

C:\Documents and Settings\Steve Zweig\CALLIE\Desktop\Second Shelf Life Conference\demo...
First reading:

C:\Documents and Settings\Steve Zweig\CALLIE\Desktop\Second Shelf Life Conference\demo...
Milbond , ID Code: 128000
Waiting for d Security code: 56541, Checksum: 7979 vs 7979 OK
Port status: Status: OK <86.9 % life remaining>
Hours elapsed since LifeTrack start: 20
Hours run: 20, Average temperature: 25.7 +/- 0.2 C
Milbond ~ 1
00C~00000000~

C:\Documents and Settings\Steve Zweig\CALLIE\Desktop\Second Shelf Life Conference\demo...
Temperature logger <degrees C>:
Logger frequency: 0.5 hours, total logger time: 20.5 hours

Temperatures recorded
[- 20.5 hr.] 26, 26, 27, 27, 27, 27, 27, 27, 27, 27,
[- 15.5 hr.] 27, 27, 26, 27, 26, 26, 26, 26, 25, 25,
[- 10.5 hr.] 25, 25, 25, 26, 26, 26, 26, 25, 25, 25,
[- 5.5 hr.] 25, 25, 25, 25, 25, 25, 23, 24, 23, 24,
[- 0.5 hr.] 25,


Logger still running when downloaded.

Enter notes. End with a 'q' to quit: _
```

# Output data includes

- ID name and ID code
- Unique security code that changes on reset
- Time unit has been running
- Time since unit expired
- Temperature statistics
- Pre-expiration temperature log (50 hours to 400 days).

# Data output example



# Example: Evaluation at Walter Reed

- Blood storage life depends greatly on temperature
- Often shipment conditions are not ideal
- LifeTrack units may help distinguish properly shipped blood from improperly shipped blood.
- Victor MacDonald, M.D., Chief of Blood Storage Branch is presently evaluating various LifeTrack blood storage programs

# Cost and availability

- Cost: \$20 per unit
- Availability: In production, available now

# CliniSense Contact Information

- POC: CEO
  - Telephone (408) 348-1495
  - Address: 15466 Los Gatos Blvd.,  
109-355, Los Gatos, CA 95032
  - Web site: [www.clinisense.com](http://www.clinisense.com)
  - DUNS number: 135973738
  - DOD CAGE code: 3KCL9; CCR #:  
WZF974