

# The CliniSense LifeTrack™




10/22/03

CliniSense Corpo  
ration


# About CliniSense

- Located in Los Gatos, CA (Silicon Valley)
- Founded in 2001
- Privately funded
- Medical diagnostics and instrumentation background
- Emphasis on quality and precision




# Shelf Life Issues

- Shelf life is determined by both time and temperature
- Most materials deteriorate faster at high temperatures
- Some materials “die quickly” at temperature extremes



# The ideal shelf-life indicator

- Is accurate
- Immediately tells if the product is still good
- Has a “gas gauge” to show remaining shelf life
- Can provide a detailed product history record upon request




10/22/03

CliniSense Corporation


# Previous shelf-life instruments

- Chemical indicators show shelf-life, but are not flexible or accurate
- Electronic temperature loggers are accurate, but don't show shelf-life.
- Temperature alarms only show extreme “out of bounds” conditions




# The CliniSense LifeTrack™

- Monitors and analyzes temperature history
- Programmed with a material's sensitivity curve
- Displays remaining shelf-life
- Downloads data to a computer



# The stability bank algorithm





Stability bank  
"B"

10/22/03

CliniSense Corporation

# Stability calculation example


$$B = 165984 - \sum_0^{\text{time}} P(\text{temperature})$$





# LifeTrack Display

- Shows “+” when product is good, “-” when product has expired
- Lifetime indicator bars decrease as the lifetime is used up



# Applications

- Algorithm can track stability ranging from “ice cream” to “rubber tires”
- Medical products & drugs
- Biodefense Diagnostics
- Food
- Chemicals
- Temperature sensitive rubber and plastics




10/22/03

CliniSense Corpo  
ration

10

# The LifeTrack unit



10/22/03

CliniSense Corporation


11

# Data transmission (standard unit)

- Infrared link to Optical RS232 cable
- Compatible with Windows & Linux
- Can be interpreted on the spot or directed to a remote web site
- “Open system” users can control data & applications



# Data output example





# Simple internet connectivity

- Downloaded data pastes directly into a standard web browser address bar
- Data is transferred to remote internet servers, & processed by the standard “CGI GET” protocol
- Data can be stored in any internet server and used as needed



# Security: Is the data genuine?

- Generates a unique random number when reset
- Number is scrambled (weak encryption) for transmission
- Users can compare beginning number with end number
- If matches, is OK (FDA 21 CFR part 11 compatible)



# Accuracy

- Unit designed for multi-point calibration to NIST standards
- Each calibration point requires a separate step
- Two point calibration (0 °C, 40 °C) standard to +/- 0.5 °C
- Additional calibration points on special order






# Expansion port capabilities

- Enables rapid customization, modules developed upon special order:

- Extra memory
- RFID radio link
- Larger battery
- External sensor(s)
- Sonic alarm
- Electrical switch



# Battery life

- Unit uses an ultra-low power microprocessor
- Standard unit uses a CR2032 battery - 2 years
- Custom plug-in expansion battery upon special order
- Custom case with a larger 10 year battery can also be produced (special contract)



Standard  
CR2032  
battery


# Cost and Availability

- Basic unit (includes logger, IR output, 2 year battery, 2 point calibration) about \$20 in volume
- Programming NRE fee
- Units are reusable
- Timetable
  - Evaluation units 1Q '04
  - Lead-time from PO to production ~2 months



# Production capability

- Product based on a Texas Instruments microprocessor
- CliniSense design, IP (patents pending), calibration and temperature programming
- Assembled in China, high volume production facility
- Rapid ramp-up is possible



# Interested groups include:

- Air Force Battlelabs
- SBCCOM
- USAMMA

# CliniSense Contact Information

- POC: Stephen Zweig, Ph.D. CEO
  - Web site: [www.clinisense.com](http://www.clinisense.com)
  - DUNS number: 135973738
  - DOD CAGE code: 3KCL9; CCR #: WZF974